


# **ZM3** Series



| ZM3 | R | 06 | W | Т |  |
|-----|---|----|---|---|--|
| 1   | 2 | 3  | 4 | 5 |  |

| ①Valve's type           | @Model  | ③Port size | <b>④ Extreme angle of opening and closing of control head</b> | <b>⑤Thread type</b> |
|-------------------------|---|------------|---|---------------------|
| ZM3: ZM type<br>3/2 Way | R: Roller type<br>J: Adjustable roller type<br>P: Contact pin<br>adjustable roller type | 06: 1/8"   | Blank: Standard type<br>W: Large angle type                   | T: NPT              |

# **Specification**


| Model               | ZM3R                                | ZM3J   | ZM3P |  |  |
|---------------------|-------------------------------------|--|------|--|--|
| Operating           | External control direct acting type |  |      |  |  |
| Fluid               | Air (to                             | Air (to be filtered by 40 μm filter element) |      |  |  |
| Pressure range      | -15~145psi(-0.1~1.0MPa)             |  |      |  |  |
| Proof pressure      | 215psi(1.5MPa)                      |  |      |  |  |
| Temperature         | -20~70°C                            |  |      |  |  |
| Valve type          | 3/2 Way                             |  |      |  |  |
| Orifice size        | 6.0mm²(Cv=0.34)                     |  |      |  |  |
| Port size [Note1]   | 1/8"                                |  |      |  |  |
| Lubrication [Note2] | Not required                        |  |      |  |  |
| Material of body    | Aluminum alloy                      |  |      |  |  |
|                     |                                     |  |      |  |  |

[Note1] NPT thread is available.

[Note2] Once lubricated air is used, continue with same medium to optimize valve life span.

It is suggested to use ISO VG32 lubricant or the oil with the same grade.

## Flow chart








# **ZM3 Series**


### **Product feature**


1. The activity direction could be changed(Only adapt to standard type, large angle type unavailable)




Position of standard activity

2. The rolling wheel could be installed at the inside of leverage








3. Installation position of leverage could be changed



4. Direction of head part could be changed








The contact pin still could be used if deformation appears, but the minimal bending radius should be chosen when it is lager than 10R.

### **Inner structure**

#### ZM3R




| No. | Item          | No. | Item          |
|-----|---------------|-----|---------------|
| 1   | Bottom cover  | 13  | Spring holder |
| 2   | O-ring        | 14  | Spring        |
| 3   | Spring        | 15  | Screw         |
| 4   | Spacer        | 16  | Front cover   |
| 5   | Spool         | 17  | Bushing       |
| 6   | Body          | 18  | Shaft         |
| 7   | O-ring        | 19  | Roller        |
| 8   | Spring washer | 20  | Rocker arm    |
| 9   | Spring        | 21  | Screw         |
| 10  | Mandril       | 22  | Rotation axis |
| 11  | O-ring        | 23  | O-ring        |
| 12  | Bushing       |     |               |



# **ZM3** Series

### **Dimensions**


### ZM3R



| <b>Model</b> \Item | F.O.F | P.T. | О.Т. | T.T. |
|--------------------|-------|------|------|------|
| ZM3R06             | 20N   | 20°  | 30°  | 50°  |
| ZM3R06-W           | 20N   | 25°  | 50°  | 75°  |

### ZM3J






| <b>Model</b> \Item | F.O.F [Note1] | P.T. | 0.Т. | T.T. |
|--------------------|---------------|------|------|------|
| ZM3J06             | 20N           | 20°  | 30°  | 50°  |
| ZM3J06-W           | 20N           | 25°  | 50°  | 75°  |

[Note1] When the length of leverage is 38.1mm


### ZM3P



| <b>Model</b> \Item | F.O.F [Note1] | P.T. | O.T. | T.T. |
|--------------------|---------------|------|------|------|
| ZM3P06             | 2.3N          | 20°  | 30°  | 50°  |
| ZM3P06-W           | 2.3N          | 25°  | 50°  | 75°  |

[Note1] When the length of leverage is 141.2mm

### **Description of symbol**



- F.P. Free position: the position of control head when no external force applied:
- O.P. Activity position: the position when the control head is applied with external force and the valve is switched;
- T.T.P. Extreme position of actuation: position of control head when it is pushed until end position;
- O.F. Actuation power: when driving from free position to actuation position, the operation power applied on control head;
- F.O.F. Extreme actuation power: when driving from free position to extreme actuation position, the operation power applied on control head;
- P.T. Free route: movement distance or rotation angle from free position of control head to actuation position;
- O.T. Actuation route: movement distance or rotation angle from actuation position of control head to extreme actuation position:
- T.T. Total route: movement distance or rotation angle from free position of control head to extreme actuation position;

